



1PPS comparator: Threshold = 2V (TTL)
 Frequency counter: Threshold = 0V (RF)