



NOTES:

1. APPLY TORQUE SEAL
2. APPLY CONTACT SEALANT

PROVIDE MOUNTING HARDWARE AS REQUIRED