



Voice-coil actuator: wire 25-AWG, 140 turns.
Use only kapton insulated wires approved by LIGO, all other kinds of enamel are forbidden.

The straight section of the coils must be immobilized with a spray of Cycom 3002 kaptom enamel diluited with 25% of chemical purity ethanol, baked at 90 °C for 1 hour and 177 °C for 15 minutes in a clean air oven.

SEE DRAWING 105

	chang		27-11-	-06					
	addec		26-09-06						
	modif		25-09-	-06					
	addec	ed plate for winding					14-09-06		
ref.		note				date	date		ure
'		modific	<u>a</u> †	ions					
129	134	magnet base							
128	133	coil 1/2 spools		281	134	4 wind	winding plate		
127	133	central flux guide		275	134	4 sti-	stiffer		
126	133	flux guides		274	134	4 base	base support coil		
125	133	coil tray		273	134	4 sti-	stiffening		
124	134	coil spool base		272	134	4 supp	support magnet		
	draw.	added legend		ref.	dra	w.	added I		

			R.De Salvo			
	LIGO	PROJECT	G.Gennaro-PROMEC			
			date			
title		12-12-04				
HAM-	-OPTIC	LIGO-D051111-05-D				
AC	CTUATOR GR	scale 1:1	A 1			

10