advancedligo

Process Traveler Accu-Glass Cables LASTI

DCC Number: E070193-00-X

Date Prepared: 05-14-2007

Originator		Cognizant Engineer	Ext./Phone#		Project	Account Number	
Name Stephany Foley	Ken	Mason	#617-253-4824				
Dwg/Part Number	Rev	Part Descrip	Part Description		Serial Num	ber Qty	
1) Accuglass#104101		PEEK 25 Pin Adaptors				9	
2) Accuglass#111152		PEEK Zip Tie Mounts				88	
3) Accuglass#111155		PEEK Zip Ties				200	
4) Accuglass#101011		Power Connectors				8	
5) Accuglass#101001		Power Pins				40	
6) Accuglass Cable		Cable With 25 Pin Connectors				6	
7) Accuglass Cable		Pigtail Cable, Power Connectors				1	
8) Accuglass Cable		Pigtail Cable, 25 Pin Connectors				1	
Used In (next higher assembly):							
Vendor Name					PO/Contract	Number	
Data Package, Receiving/Inspection Remarks:							
Data Fackage, Receiving/Insp		nai No.					

Inspection Required Y/N	Visual Damage Y/N	Comments	Name/ Initials	Date Comp.
yes	none			

Process Flow:

	#	Operation	Start Date	Work Area	Instructions	Name/ Initials	Date Comp.
1		Clean		CIT	per E960022, with the following special instructions or	R. Taylor	
					cautions: Isopropyl Only		
2	2	Vacuum Bake		CIT	per E960022 to a temperature of 120C	R. Taylor	
3	3	Control Point		NA	Review/approve RGA scan #C8607_LASTI	D. Coyne	

N.B.: A copy of this traveller must be submitted to the DCC each time the original is shipped with the associated part(s) and when the traveller has been completed.

advancedligo

Process Traveler Accu-Glass Cables LASTI

DCC Number: E070193-00-X

Date Prepared: 05-14-2007

#	Operation	Start Date	Work Area	Instructions	Name/ Initials	Date Comp.
	Wrap & Tag vacuum clean parts per E960022-A			Wrap (UHV foil) and bag (CP Stat or equiv.) per E960022.	R. Taylor	
5	Deliver/File paperwork			Make 2 copies of the Traveler. File one copy with the DCC. Note: Ship original traveler with these parts.	R Taylor	
END: Go to Traveler or procedure associated with next higher assembly processing						

Special Instructions (Handling/Packaging Constraints, Remarks, etc.) or Notes:							