

THE UNIVERSITY
OF ADELAIDE
AUSTRALIA

High Power Lasers for Advanced LIGO

Jesper Munch

D. Mudge, D. Hosken, P. Veitch, M. Hamilton, M. Ostermeyer

Optics and Lasers Group
Department of Physics and Mathematical Physics
The University of Adelaide

LSC, Livingston, March 2003

LIGO-G030072-00-Z

Objectives

- Investigate high power lasers for Advanced LIGO
- Build Deployable Lasers:
 - 10W for Gingin
 - 10W for TAMA
 - 50 - 100W for Gingin High Power Test Facility
 - 100W prototype for Adv LIGO concept test

Content

- High power laser requirements
- Design issues
- Review of approach
- Progress to date
- Optimum design recommendations
- Plan for future work

Advanced LIGO laser requirements

TEM ₀₀ Power	$\geq 180 \text{ W}$
Non TEM ₀₀ Power	$< 5 \text{ W}$
Frequency Noise	$\leq 10 \text{ Hz}/\sqrt{\text{Hz}}$ (10 Hz)
Amplitude Noise	$\leq 2 \times 10^{-9} / \sqrt{\text{Hz}}$ (10 Hz)
Beam Jitter	$\leq 2 \times 10^{-6} \text{ rad}/\sqrt{\text{Hz}}$ (100 Hz)
RF Intensity Noise	0.5 dB above shot noise at 25 MHz for 150 mW

Laser Design issues

Simultaneous achievement of high power, TEM₀₀ and low noise:

- Getting to high power is (now) the easy part
(eg/ TRW MOPA design → 25 kW)
- Excellent beam quality (eg TEM₀₀) at high power is more elusive, and limited by thermo-optical properties of gain medium:
 - thermal wavefront distortion in MOPAs
 - loss of mode control in oscillators
- Low noise at high power requires well saturated gain everywhere to minimize ASE. Eg: use:
 - Zig-zag slab
 - oscillator matched to gain medium
 - unstable resonator (near flat top mode)

Design choices

Gain Medium Configuration:

Slabs: allow uniform pumping, cooling, zigzag propagation, saturation, efficiency

Rods: simple, power scaling limited by thermal effects
gain/mode spatial mismatch

Pumping:

Side pumping: Simple extension of existing design. Pumping and cooling scaling together. Use fiber coupling to place gain where needed.

End pumping: Initially believed unattractive: fills whole crystal.

Optical Configuration:

Injection locked unstable resonator: optimum control of gain saturation, mode control, extraction efficiency


MOPA: simple, but offering less wavefront control

Design approach


- Our side-pumped, 5W injection locked slab design met or exceeded LIGO I requirements. Used for scaling to 10W
- Our power scaling concept, using stable-unstable injection locked resonator worked as expected in 30 W design verification laser tests
- Extended design to 100 W by
 - increasing gain to support larger magnification unstable resonator
 - increased pump/cooling heights to increase the mode size
 - using high power diode-lasers, and larger optical fibres

5 W Laser


- Relative Intensity Noise (RIN) meets LIGO I requirements
- Frequency noise when injection locked is limited by the frequency noise of the master laser




10 W Laser




10 W Laser prototype




Measured near- and far-field beam profiles from unstable resonator



Stable-unstable laser injection locked




free-running slave




master laser on

100 W Laser



Side-pumped, side-cooled laser head



100 W laser head


Power Scaling

Initial power roll-over
observed due to:

- (A) Thermal lensing
- (B) Depolarization

Strategy for
correction:

- (A) Revised pump geometry
- (B) New high quality crystals
 - orientation
 - polishing tolerance




100 W Laser results

- **Laser head design difficult to scale to 100 W level:**
 - various laser engineering issues had to be solved:
 - laser crystal quality and orientation in boule
 - crystal cut and polish
 - pump nonuniformity, fiber degradation
 - vertical and horizontal thermal lenses can be controlled
 - larger diameter optical fibres couple to the diode-lasers without degrading SMA fibre connectors
 - planar waveguides reduce pump non-uniformity to acceptable levels
- **Laser power currently limited to ~ 80 W:**
 - birefringence in regions of strong thermal gradients outside pumped region degrades mode
 - continuing work on vertical thermal engineering
- **Use of single mode resonator requires more uniform gain medium**

Latest results: Homogeneous pumped region

Left: Horizontal negative pump power dependent thermal lens due to degrading optical fibre transmission (600 micron core) & non-homogeneous horizontal pump distribution (hot spots from optical fibres).

Right: Uniform pumped gain region. LZH optical fibres (800 micron core) and longer waveguides average pump distribution between fibres - **essentially no thermal lensing in pump region, 80W max.**



Old scheme

New scheme

Lessons Learned: Optimum design

- Need excellent pumped gain uniformity:
 - zigzag slab
 - pump uniformity
 - horizontal and horizontal thermal lens control
- Avoid large regions of varying temperature gradients to minimize effect of thermal birefringence on mode
- Achieve good overlap of mode and uniform gain region
- Side pumped slab gain design not easily scaled to 100W
- Need alternative, optimized gain medium configuration to demonstrate injection locked oscillator
- End pumped conduction cooled slab attractive alternative
- Retain unstable, supergaussian resonator for mode control and beam quality

New slab laser head design

Revised laser head designed to provide improved efficiency and thermal performance: similar to the TRW design shown:

Improvements

- End pumping
 - improved efficiency
 - more uniform slab power loading
- New pumping geometry
 - homogeneous pumping (TRW design)
 - minimal birefringence
- Improved robustness
 - Silicon Dioxide coatings (cooler slabs)

New slabs currently being fabricated (due Aug/Sept)

Plan for future work

2003

- Finish 10 W lasers for Gingin and TAMA
- Assemble and test high power laser for Gingin
 - Continue work on current laser head
 - 100 W using new improved design (~Oct-Dec)
 - Worst case: 50 W backup, current laser head as is

2004-2009

- Proposed work:
 - “High power lasers and optical systems for advanced interferometry - an ACIGA project”*
 - Complete development of new laser head for 100 W
 - Use laser in Gingin high power test facility experiments