







The Mechanical Loss of Thin-Film Hafnia as a Function of Temperature

E. Chalkley¹, I. Martin¹, S. Reid¹, H. Armandula², R. Bassiri¹, M.M. Fejer³, A. Gretarsson⁴, G. Harry⁵, J. Hough¹, P. Lu³, I. McLaren¹, S.Penn⁶, S. Rowan¹, R. Route³, K. Vijayraghavan³, A.Woodcraft¹

¹SUPA, University of Glasgow, Scotland. ²LIGO Laboratory, California Institute of Technology, USA. ³Stanford University, USA. ⁴Embry-Riddle Aeronautical University, USA. ⁵LIGO Laboratory, Massachusetts Institute of Technology, USA. ⁶Hobart and William Smith Colleges, USA.







Overview

- Introduction: Tantala and beyond
- Experimental setup
- Measurements of low temperature dissipation in hafnia
- Applications of hafnia as a high index coating
- Calculation of hafnia/silica multilayer coating loss





Beyond Tantala Coatings


- The high index coatings required in gravitational wave detector optics have been determined to contribute significantly to detector thermal noise.
- Ta₂O₅ is the dominant source of dissipation in current coatings – mechanism under investigation.
- Ta₂O₅ is known to grow with oxygen deficiencies. HfO₂ is known to have better stoichiometry – alternate high index material.
- Is the dissipation mechanism similar?





Cryogenic Mechanical Loss Measurement

- Experimental method –
 see previous talk.
- Small, lightweight cryogenic system:
 - efficient cryogen use
 - fast cool down
 - good thermal control
- Motion sensed by cantilever shadow – very little variation of beam alignment with temperature.









University of Glasgow Cryogenic Mechanical Loss Measurement

- Sample dimensions:
 - Length = 40mm
 - Width = 10mm
 - Substrate thickness = 59.2µm
 - Coating thickness = 500nm





sensors


heaters

Cantilever substrates fabricated at Stanford and coated by CSIRO



Temperature Dependence of Coating Loss for Mode at f = 56Hz











Mode at f = 330Hz








Mode at f = 950Hz








Mode at f = 1950Hz








Mode at f = 3300Hz








Plot showing coating loss for all modes studied







Comparison with Tantala



- At 100 K, the level of mechanical loss associated with both doped tantala and hafnia appears at a level $\phi(\omega)_{coating} \sim 4 \times 10^{-4}$
- HfO₂ shows no major low temperature dissipation peak, loss appears to decrease to below 3×10⁻⁴ at ~15 K.






HfO₂ as a Coating Component

- Initial results of the mechanical loss of HfO₂ do not show a large peak in dissipation at T ~ 20K in contrast to Ta₂O₅
- Broad peaks do appear to occur at ~50K and ~200K – could this indicate a different dissipation mechanism?

 Initial room temperature studies on a multi-layer silica-hafnia coating on a fused silica substrate were found to be φ_{hafnia}=(5.7±0.3)×10-4



Calculated Loss of 31-layer Coatings



- above 130K, the silica/tantala coating has a factor of 2 lower loss
- below 70K, the silica/hafnia coating stabilizes at a loss of about 4e-4, with a very slight bump at around 20K, due to the dissipation peak in silica.





HfO₂ as a Coating Component

- However, thermo-mechanical material properties for ion-beam-sputtered thin-film HfO₂ are not terribly well studied – could change absolute values of the loss results presented here.
- The optical properties also require further investigation, where initial recent absorption studies of a multilayer silica-hafnia coating by Markosyan et al. (Stanford University) lie in the range 60-80ppm, which is considerably higher than required.