
Identifying and mitigating scattering noise in LIGO

Robert Schofield (University of Oregon) LIGO-G1300624





- 1. Scattering noise and mitigation during i/eLIGO: malfunctioning active isolation, HVAC noise, and problems on tables
- 2. Finding scattering sites: shakers, fingers, and cameras
- 3. aLIGO baffling progress

Noise in iLIGO and eLIGO that was attributed to scattering


- * Path length change large compared to wavelength: only observed when active isolation systems were malfunctioning.
- * Path length change small compared to wavelength but harmonics, not fundamental, were the biggest problems: HVAC noise
- * Path length change small compared to wavelength: many examples on optics tables

Path length change exceeded wavelength


* Malfunction of external isolation system used to accommodate microseismic peak



* Malfunction of optic table actuators



Path length change exceeds wavelength



HT


 H_2

These events during H2 malfunction (broken actuator moving test mass suspension). Show that H1-H2 back-scattering paths exist.4


Noise in iLIGO and eLIGO that was attributed to scattering

- * Path length change large compared to wavelength: only observed when active isolation systems were malfunctioning.
- * Path length change small compared to wavelength but harmonics, not fundamental, were the biggest problems: HVAC noise
- * Path length change small compared to wavelength: many examples on optics tables


Inspiral range increased by ~1Mpc when HVAC off



Blue: All site turbines and chiller pad equipment off; Red: normal




Shaking to study HVAC coupling






HVAC effect from shaking of optic support structures but not from shaking optic by itself

RED: shaker injection, 16 Hz; BLUE: servo injections to match pitch, yaw and displacement from shaker injection




Noise from shaker injection was consistent with HVAC effect, but noise from test mass actuator injection was too small. This eliminated our Barkhaussen noise problem as the source of the HVAC effect and suggested scattering from optic support.

Shaker noise was consistent with simple scattering model




Candidate site for HVAC coupling

Shaking of each test mass structure indicated that worst locations had transmission monitors (with reflective supports)



Broad-band seismic signal from HVAC was produced by plenum turbulence (noise did not require duct flow)





For eLIGO, HVAC shaking reduced by screens to break up large eddies. For aLIGO we will have better baffling and screens.




Noise in iLIGO and eLIGO that was attributed to scattering


- * Path length change large compared to wavelength: only observed when active isolation systems were malfunctioning.
- * Path length change small compared to wavelength but harmonics, not fundamental, were the biggest problems: HVAC noise
- * Path length change small compared to wavelength: many examples on optics tables

Backscattering from bright ghost beam dumped on optic mount

Damage is mostly due to fundamentals, not harmonics




BACKSCATTER FROM UNUSED S5 SHUTTER MAKES DARM PEAKS IN S6



Backscatter from bad beam dump


"Blackhole" dumps were about the same as white paper.




Reminder: most of the vibration-related noise in LIGO was not from scattering

- * We had to reduce acoustic noise in DARM by 3+ orders of magnitude. We did this based on indications that the coupling was mainly from clipping by optics on tables (EO shutters were worst), and beam motion on the photodiodes (which did not have uniform responses). We distinguished these coupling mechanisms from scattering using neutral density filters and irises as well as other techniques.
- * Our biggest source of noise from low frequency seismic motion was Barkhausen magnetic domain flipping noise.


Quick and easy (but not perfect) check – since coupling with low frequency motion is very non-linear, scattering noise is very susceptible to bilinear upconversion, while for many non-scattering coupling mechanisms, a monochromatic environmental injection makes a sharp DARM line.




Finding scattering sites: shakers



17 sites investigated




Worst back-scattering sites






Worst sites

End cap of beam tube









End cap of beam tube

Accelerometer mounted near shaker on center port of BSC9 (EX) end door



Shaking evident on H2 even though the nearest component was 2km away


T0=18/05/2007 23:54:30



Avg=30

BW=0.187499

Worst* scattering sites (); proposed S6 baffles (,,)




Y-manifold baffle






HAM5 baffle







X-endcap baffle



Y-endcap baffle






Finding scattering sites: bowing or plucking


Squeezing at LHO: we bowed numbered optics using finger ridges.


With Sheila Dwyer and Sheon Chua



Identifying optics peaks in DARM


BLACK: nominal DARM, RED: bowing optic 10






Temporary solution

Weighted damping material set on top, rather than damping of individual optics (which would require redoing the beam path)






Finding scattering sites: camera techniques for glints

Using a camera with its flash near its lens to qualitatively observe sites that back-reflect, keeping in mind that angular distribution of light from flash can be very different..


* Beam spot view: camera placed as near as possible to beam spot to observe any surfaces that retro-reflect light scattered from optic




* Distant optic view: camera placed far from optic, in beam path (flash reflects in optic), to observe glints that retro-reflect light scattered from distant optic

Beam spot view (iLIGO)

X-manifold - view from ITMX



Before




After

Distant optic view (iLIGO)


White circles: region visible to ETMs (approx. clear aperture)

X-arm ITMs (S5)


Y-arm ITMs (S5)



X-endcap baffle




Y-endcap baffle






aLIGO Baffles


Arm cavity side of test masses, 1 spring + HEPI isolation, damped





Mode cleaner tubes, input and output, 1 spring isolation, damped








aLIGO Baffles


Input test mass elliptical, on beam splitter side, 1 spring + HEPI isolation, damped







aLIGO Baffles

Beam splitter elliptical, same isolation as active table







Distant optic view, baffle check (aLIGO, arm cavity-v1)




Beam spot view, baffle check (aLIGO arm cavity – v1)








Left side Center







Center Right side


Beam spot view from back of ITM's

Looking towards beam splitter through ITM elliptical baffles

from ITMY







Beam spot view from beam splitter

Note bright reflection from ITM cage: we had not considered this – a baffle may be needed

